

Turn Off Firmware Updates Operation Guide - Laser MFP

HP 215/216



Step 1

Click "OK"




Click ▷ Select "Service" and click "OK"

Step 2




Step 3

Click ▷ Select "LaserJet Update" and click "OK"




Click ▷ Select "Manage Updates" and click "OK"

Step 4



Step 5

Click ▷ Select "Check Automatically" and click "OK"




Click ▷ Select "Off" and click "OK"

Step 6



Step 7

Click ▷ Select "Allow Updates" and click "OK"



Click ▷ Select "No" and click "OK", click ↶ to complete setting.

Step 8

Suitable For : HP LaserJet Pro MFP M182/183
M155 needs to be confirmed

Turn Off Firmware Updates Operation Guide - Laser MFP

HP 205/206



Suitable For : HP LaserJet Pro MFP M282/283

Turn Off Firmware Updates Operation Guide - Laser SFP

HP 205/206



Step 1

Click "OK"



Click ▷ Select "Service" and click "OK"

Step 2




Click ▷ Select "LaserJet Update" and click "OK"

Step 3




Click ▷ Select "Manage Updates" and click "OK"

Step 4



Click ▷ Select "Check Automatically" and click "OK"

Step 5




Click ▷ Select "Off" and click "OK"

Step 6



Click ▷ Select "Allow Updates" and click "OK"

Step 7



Click ▷ Select "No" and click "OK", click ↶ to complete setting.

Step 8

Suitable For : HP LaserJet Pro M255

Turn Off Firmware Updates Operation Guide - Laser SFP

HP CF258/259/276/277/414/415/416



Step 1: Click "OK"



Step 2: Click "OK"



Step 3: Click ▷ select "Printer Maintenance" click "OK"




Step 4: Click ▷ select "Update Firmware" click "OK"




Step 5: Click "OK"



Step 6: Click ▷ select "Update Options" Click "OK"



Step 7: Click ▷ select "off" Click "OK"



Step 8: Click "X"




Step 9: Click ▷ select "Manage Updates" Click "OK"



Step 10: Click "OK"



Step 11: Click ▷ select "NO" Click "OK"



Step 12: Click "OK" and Click ↶ to complete setup

Suitable For : HP LaserJet Pro M305/404/405;M454

Turn Off Firmware Updates Operation Guide - Laser MFP

HP CF258/259/276/277/414/415/416



Suitable For : HP LaserJet Pro MFP M329/428/429; MFP M479